



45

Truss Head Screw locations.



46

Slide a supplied .700" washer onto a supplied Torx Screw.



47

Start Screws/Washers through pocket holes in Outer Flare and into Threaded Clips installed in Step 18 (8 places). **Do not tighten.**



48

Pull tape liner from tape and press part to vehicle to secure adhesive backing. Tighten all Truss Head Screws first, then tighten all Torx Screws, moving from back to front.