



Combination Pack Seat Cover, Steering Wheel Cover and Shoulder Pad



**Front and Rear
Polycanvas & Neoprene**

Parts List:

Front 2- Seat Covers, 2-Shoulder Pads, 1-Steering Wheel Cover
Rear- Cover set and 2 Shoulder Pads

Installation:

Front Seat Covers:

- 1) Begin on either Drivers or Passenger seat, by moving seat to its forward position for better access.
- 2) Pull seat cover over seat back, cover will fit on either Drivers or Passenger seat. Note: For 03-05 applications the drivers and passenger seat cover will have an opening for the seat back adjustment lever on the side near the top of the cover.
- 3) Pull flap located on the inside of the cover, at the lower seam of front panel and seat bottom, through the crack between the seat back and seat cushion.
- 4) Tighten the laces on both sides of cover snugly. Begin on one side of the cover by feeding the two ends of the lace through the bungee loop located at the back flap of the seat bottom. Then feed one lace through the grommet in the back of the cover and then through the flap pulled between the seat back and bottom. Pull the other lace under the seat and tie the two ends of the lace together. Repeat on other side of cover. Store excess lace material under seat.
- 5) Repeat 1 to 4 for other seat.

Steering Wheel cover:

- 1) Stretch wheel cover over wheel by working the cover around the steering wheel. Cover should fit snugly.

Shoulder Harness covers:

- 1) Open Velcro flap and wrap around the shoulder harness at desired comfort area. Close Velcro.

Rear:

Each set is comprised of two pieces, Seat back and seat bottom and shoulder harness.

- 1) Seat back slides over the back of the seat with the pocket towards the back of the seat, tuck through the opening at the bottom and fasten hook and loop together to form a tight fit. Pull laces on the sides tight to remove any excess material. Seat bottom fits over seat and , the hook fastens to the carpet, material on the bottom of your factory seat. 03-05. 97-02 use straps under the seat to attach.**
- 2) Shoulder harness, see step 1 above for front seats.**

Washing Instructions:

Do not Machine wash. Use a mild soapy waster solution to get out stains. Do not rub to hard in one place on Neoprene as this can harm the material. Let Air dry.

Rampage Products
Buford, GA
Phone: 800-328-2409
www.rampageproducts.net
Made in China